ON Semiconductor®



Test Procedure for the 60WLEDBULBGEVB Evaluation Board

The following steps detail the basic test procedure for these boards:

<u>Necessary Equipment:</u> 1 120 VAC Source 1 Yokogawa WT330 Digital Power Meter




Figure 1: Test Setup

Test Procedure:

- 1. Check if all of the components have the right values and are mounted in the correct positions.
- 2. Connect the test setup as shown in Figure 1.
- 3. Apply an input voltage, $V_{IN} = 120 \text{ VAC}$
- 4. Check that P_{in} is about 10W.
- 5. Check that THD is between 15-20%.
- 6. Check that power factor is between 0.96-0.99.
- 7. Power down the input.
- 8. End of test

Be careful when manipulating the boards in operation, lethal voltages are present.